

# MJR-7000 PROGRAM MANUAL

**SECTION 1: CLOCK AND CALENDAR PROGRAMMING AREA**  
**TO ENTER PROGRAM AREA - TURN THE KEY AND PRESS** 1 0 E

PROGRAM ADDRESS NO.	SAMPLE DATA	PROGRAM CODES AND EXAMPLES	PROGRAM DATA
000 1	1 9 9 0 #	Calendar year	#
----- 2	4 3 0 #	Month and Date	#
----- 3	1 5 2 8 E	Hour and Minute (24 hour format)	E

**SECTION 2: BASIC PROGRAMMING AREA**  
**TO ENTER PROGRAM AREA - TURN THE KEY AND PRESS** 2 0 E

PROGRAM ADDRESS NO.	SAMPLE DATA	PROGRAM CODES AND EXAMPLES	PROGRAM DATA
001 1	3 1 1 #	Date Daylight Saving Time Begins (Ex: April 1)	#
----- 2	1 1 0 4 E	Date Daylight Saving Time Ends (Ex: October 28)	E
002 1		Machine Number 0 - 9 : Time Cards No. 000-099, enter 0 Time Cards No. 100-199, enter 1 Time Cards No. 200-299, enter 2 Time Cards No. 300-399, enter 3 : : : : Time Cards No. 900-999, enter 9	E
003 1		Imprint of hours for IN/OUT times: 0 = 0-23 Hour format (military time) 1 = 1-12/1-12 AM/PM Hours	#
----- 2		Imprint of accumulated minutes: 0 = Regular minutes (00-59) 1 = 1/100 of hour (00-98)	#
----- 3		Printing of Day of week: 0 : English days (MO...SA,SU) 1 : Day numbers (1...6,7) 2 : French days (LU...SA,DI)	E

**IMPORTANT: UPON COMPLETION OF THE GENERAL PROGRAMMING AREA, BE SURE TO PRESS THE** I **KEY TO SAVE THE DATA INTO MEMORY.**

- Turn key back to "NORMAL" mode.